

Using the Quick Settings Panel



12%


10:01 PM



How to Turn on GPS on Android

1 Swipe down from the top of your screen. Place your finger at the top of your Android's screen, and slide it down. It will open your Notification Center in a drop-down panel.

- You don't have to unlock your Android to open Notification Center.

A screenshot of an Android status bar. The background is dark grey. On the left, the time '10:07 PM' and the date 'Saturday, September 30' are displayed in white. On the right, there are four icons: a Wi-Fi signal icon, a cellular signal strength icon, a battery level icon, and a user profile icon. The entire status bar is highlighted with a thick green border.

10:07 PM

Saturday, September 30




No notifications

2

Tap the Quick Settings icon. It looks like a small gear with white squares around it in the upper-right corner of Notification Center. This will open your Quick Settings menu in the drop-down panel.

- If you tap the bigger gear icon, you will switch to your Settings app.

Using the Quick Settings Panel



How to Turn on GPS on Android

3 Tap **Location** on the Quick Settings panel. The Location icon will turn bright white or blue when it's on. This option turns all Location services on for your phone and tablet.

- The Location icon may look like a pin or a world icon depending on your Android version.
- On some versions of Android, this option is listed as **GPS**.

Using the Settings app



How to Turn on GPS on Android

1

Open your Android's Apps menu. It's a grid or list of all the apps installed on your phone or tablet.

Using the Settings app



2



Tap the  icon on the Apps menu. It will open your Settings app.

Personal



Location



Security



Accounts

How to Turn on GPS on Android

3

Scroll down and tap **Location** on the Settings menu. This option is listed next to a pin icon under the PERSONAL heading.

- If you don't see Location on your Settings menu, look for **Privacy & Safety**. On some versions, Location is listed under this option.



Location

On



Mode

High accuracy

Recent location requests

How to Turn on GPS on Android

4

Slide the switch at the top to  position. This switch is located in the upper-right corner of your Location menu. It will turn all Location services on for your phone and tablet.



Community Q&A

Unanswered Questions



I'm wondering how to use access code to call my target phone? I'm unable to download the app on my target phone. Help please.?

Answer this question

Show all



Settings



Search engine
Google

Autofill and payments

Save passwords

Advanced

Privacy

Accessibility

Site settings

Language

Data
0% data savings

About Chrome





Site settings



All sites



Cookies

Allowed



Location

Ask first



Camera

Ask first



Microphone

Ask first



Notifications

Ask first



JavaScript

Allowed



Pop-ups

2



Location



Location

Ask before allowing sites to know
your location (recommended)



Allowed - 1



<https://www.google.com.eg>

3